


Quick Guide

- SmartShare FairRouter

1. Connect the FairRouter between your Modem and Switch

- FairRouter WAN port → Internet modem's LAN port
- FairRouter LAN port → company network switch. Use straight (gray) Ethernet cables
- *After* connecting the Fair Router , turn the power on



2. Check the LED Indicators

- Power: ■ ON
- LAN and WAN ports ■ ON = OK / □ OFF = No Connection. Use a crossed (red) Ethernet cable instead
- STATUS: ■ ON = starting up (5 minutes max.)
■ □ Blinking green = OK / ■ □ Blinking red = Problem detected

3. Open the Web GUI

- Open the Web GUI from a PC in your company network

Web address: The IP Address is shown on the LCD display

Password: admin
Password: admin